

Do not use PWM; simply turn it on or off—do not leave it partially on, as this causes the op-amps to oscillate.

The IRFP260N MOSFETs are mounted on the heatsink with screws, not on the circuit board.

When applying voltage to the protected input, ensure that the voltage is 8 V or higher, as the protection MOSFETs will not fully turn on. A voltage between 0 and 30 V can be applied to the unprotected input.

